Pioneer

Service Manual

ORDER NO.
RRV2303

SPEAKER SYSTEM

S-W39 XEE
S-W39 XEB

FOR PRECAUTION OF REASSEMBLY AND DISASSEMBLY

- The rear panel is attached to the inner baffle by 6 screwing. To detach it, pry it open by unscrewing with a cruciform screwdriver. Be careful not to damage the wood panel.

- The woofer is attached to the baffle by 4 external screws. To detach it, first remove the rear panel. Next unfasten those screws. Then remove the woofer. When attaching it, face its terminal downward.

PIONEER CORPORATION 4-1, Meguro 1-chome, Meguro-ku, Tokyo 153-8654, Japan
PIONEER ELECTRONICS SERVICE, INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE N.V. Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
© **PIONEER CORPORATION 2000**

T-ZZK APR. 2000 Printed in Belgium

PARTS LIST

NOTES : ● *Parts marked by "* NSP *" are generally unavailable because they are not in our Master Spare Parts List.*
● *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*

Mark	No.	Description	Part No.
		Input Terminal	FRKX-008
		Network Assy	FRWN-100
		Speaker (WF)	P10EC65-57D
		Screw (for WF)	FRBA-011
		Screw (for Rear Panel)	FRBA-016
		Ring	FRNK-141
		Badge	FRAM-035

For Packing

Mark	No.	Description	Part No.
		Speaker Wire	FRDD-042
		Protector	FRHA-185
		Packing Case	FRHG-265
		Plastic Bag	FRHL-031
		Operating Instructions	FRRD-137

SCHEMATIC DIAGRAM

Network Assy (FRWN-100)